

## *Apple Cleaning & Sanitizing on Packing Line Guide*

<b>Condition</b>	<b>Dump Tank</b>	<b>Cleaner</b>	<b>Sanitizer</b>	<b>Fungicide</b>	<b>Coating</b>	<b>Comments</b>
<b>Very Little Calcium &amp; Some Loose Soil</b>	<i>Agchlor 310</i> 50 –100 PPM Total 20 -50 PPM Min. Free  <i>DECCO Buffer 312 or 313 or 314</i> pH 6.5 to 7.5	<i>F&amp;V Kleen 241 or 340</i>  7-8 pH	<i>Peraclean</i>  80 – 100 PPM PAA	<i>DECCO Salt#19</i> Line Spray 600 PPM Wax Spray 1000 – 2000 PPM or <i>Penbotec 400SC</i> Line Spray 1000 PPM Wax Spray 2000 PPM	<b>Carnauba or Shellac</b>  Consult DECCO Rep	Rinse completely before wax.  Waste Water Discharge must comply with Safe Drinking Water Act
<b>Calcium &amp; Mineral Deposits</b>	<i>DECCO Buffer 312 or 313 or 314</i>  2 – 3 pH	<i>Apl Kleen 245 or 246</i>  2 – 3 pH	<i>Peraclean</i>  80 – 100 PPM PAA	<i>DECCO Salt#19</i> Line Spray 600 PPM Wax Spray 1000 – 2000 PPM or <i>Penbotec 400SC</i> Line Spray 1000 PPM Wax Spray 2000 PPM	<b>Carnauba or Shellac</b>  Consult DECCO Rep	Rinse completely before wax.  Waste Water Discharge must comply with Safe Drinking Water Act
<b>Natural Wax</b>	<i>F&amp;V Kleen 440 or 441</i>  10 – 12 pH	<i>F&amp;V Kleen 440 or 441</i>  10– 12 pH	<i>Peraclean</i>  80 – 100 PPM PAA	<i>DECCO Salt#19</i> Line Spray 600 PPM Wax Spray 1000 – 2000 PPM or <i>Penbotec 400SC</i> Line Spray 1000 PPM Wax Spray 2000 PPM	<b>Carnauba or Shellac</b>  Consult DECCO Rep	Rinse completely before wax.  Waste Water Discharge must comply with Safe Drinking Water Act
<b>Organic Very Little Calcium &amp; some Loose Soil</b>	<i>Agchlor 310</i> 50 PPM Total Max 20 PPM Free Min <i>Citric Acid</i> pH 6.5 to 7.5	<i>DECCONatur Kleen</i>  10-12 pH	<i>Peraclean</i>  80 – 100 PPM PAA	<b>Bio-Save 10LP</b> 500 gr / 80 Gal Water	<i>DECCONatur 575 – Shellac 520 – Blend 550 - Beeswax</i>	Rinse completely  Waste Water Discharge must comply with Safe Drinking Water Act
<b>Organic Calcium Mineral Deposits</b>	<i>Citric acid</i>  2 – 3 pH	<i>DECCONatur Kleen</i>  10-12pH	<i>Peraclean</i>  80 – 100 PPM PAA	<b>Bio-Save 10LP</b> 500 gr / 80 Gal Water	<i>DECCONatur 575 – Shellac 520 – Blend 550 - Beeswax</i>	Rinse completely  Waste Water Discharge must comply with Safe Drinking Water Act

### Pears Cleaning & Sanitizing on Packing Line Guide

Dump Tank	Cleaners	Sanitizer	Fungicide	Coating	Comments
<b>Pear Float</b> Spec Grav.- Depends on variety pH 11.0 13.0  <b>DECCOSOL 122</b> 14.5% SOPP-	<b>F&amp;V Kleen</b> <b>241</b> or <b>F&amp;V Kleen</b> <b>340</b>  7-8 pH	<b>Peraclean</b>  80 – 100 PPM PAA	<b>DECCO Salt#19</b> Line Spray 600 PPM Wax Spray 1000 – 2000 PPM <b>Penbotec 400SC</b> Line Spray 1000 PPM Wax Spray 2000 PPM	<b>Carnauba Blend</b> <b>Pear Kote</b>	Waste water Discharge must comply with Safe Drinking Water Act

### Cherries & Stone Fruit Cleaning & Sanitizing on Packing Line Guide

Receiving Hydro Cooler	Dump Tank	Cleaners	In-Line Hydro Cooler Sanitizer	Fungicide	Coating	Comments
<b>Agchlor 310</b> 50 –100 PPM Total 20 -50 PPM Min. Free  <b>DECCO Buffer</b> <b>312 or 313 or 314</b>  pH 6.5 to 7.5	<b>Agchlor 310</b> 50 –100 PPM Total 20 -50 PPM Min. Free  <b>DECCO</b> <b>Buffer</b> <b>312 or 313 or</b> <b>314</b>  pH 6.5 to 7.5	<b>F&amp;V Kleen 241</b> or <b>F&amp;V Kleen 340</b>  7-8 pH	<b>Peraclean</b>  80 – 100 PPM PAA	<b>Bio-Save 10LP</b> 500 gr / 80 Gal Water	<b>PNPL</b> <b>255- Veg Oil Base</b> <b>282 – Min Oil Base</b> <b>Multi Lustr- Blend</b>	Waste water Discharge must comply with Safe Drinking Water Act